

INTERFACE

PIN NO.	SYMBOL	DESCRIPTION
1, 17	3.3V	Power positive (3.3V input)
2, 4	5V	Power positive (5V input)
3, 5, 7, 8, 10, 12, 13, 15, 16	NV	NC
6, 9, 14, 20, 25	GND	Ground
11	TP_IRQ	Touch Panel interrupt, low level while the Touch Panel detects touching
18	LCD_RS	LCD instruction control, Instruction/Data Register selection
19	LCD_SI/TP_SI	SPI data input of LCD/Touch Panel
21	TP_SO	SPI data output of Touch Panel
22	RST	Reset
23	LCD_SCK/TP_SCK	SPI clock of LCD/Touch Panel
24	LCD_CS	LCD's chip selection, low active
26	TP_CS	Touch Panel's chip selection, low active